

# Delicate balance in a tough environment: Refractory selection for fluid catalytic cracking units

By Stephen Karns

Petrochemical refining challenges refractory materials to handle not just heat, but abrasion, in changing harsh environments within the fluid catalytic cracking unit.

A fluid catalytic cracking unit (FCCU) is the heart of most oil refineries. It is here where much of the profit of a refinery can be made. This unit transforms low-value bottom-of-the-barrel tars with high molecular weights into high-value, profitable high-octane fuels and petrochemicals by breaking down the hydrocarbons. Fluid catalytic cracking is a secondary refining process that uses catalysts to produce high-octane gasolines, olefinic gases and other petroleum products. About one third of all the crude oil processed at a refinery with a FCCU is refined in this unit, making it a valuable asset. At present, there are about 135 refineries in operation in the United States. Refractory selection for FCCUs depends on where in the processing unit the refractory is placed.

In general, refractories are strong and dense, or light and soft. Every combination exists in between, and there are always tradeoffs between properties to consider when selecting refractories. Determining which of a wide variety of refractories to use in a specific area can be quite challenging. Some areas require abrasion resistance, while others need to have a better insulating effect. It helps to simplify the task and break down the unit into four main areas: the riser, cyclones, reactor and regenerator, and



Figure 1. Schematic of fluid catalytic cracking unit showing the primary components requiring refractory.

transfer lines. These areas are pointed out in Figure 1, along with other specific areas mentioned below.

#### Risers, regenerators, and cyclones

In the riser, hot catalyst feeds in from the regenerator and is fluidized and blown upward using air. Long-chain hydrocarbons, such as asphaltene and other tar-like oils, are preheated and sprayed into the fluidized catalyst. With heat and aid of the catalyst, the hydrocarbons crack and break down into shorter hydrocarbon chains such as gasoline or propylene, which are much more profitable for a refinery than the original long-chain hydrocarbon feed. This reaction also produces excess carbon that deposits on the surfaces of catalyst particles. The conditions created in the riser with this process can be hellishly extreme, so it is often a difficult area for solving refractory problems. A great deal of refractory abrasion results from the high gas velocities used to fluidize and blow the catalyst and feed upward. The heat created from the catalyst is also a concern, but the reaction is endothermic, and therefore, having the best insulation is not necessarily a primary factor.

The refractory lining in the riser is about six inches thick on the walls and is usually gunned into place. In general, the riser will need refractory with very good abrasion resistance; some specific areas will need even more thickness. As mentioned, the lining will also need more insulating value where it is possible and makes sense. For the most part, abrasion resistance of products used in risers should be rated at 10 cc loss or less (after firing to 1,500°F, tested with ASTM C704/ C704M-15<sup>1</sup>). The lower the loss value, the more abrasion resistant the refractory. Figure 2 shows an example of samples after abrasion testing.

Density is generally used to assess the insulating value of refractory; the lighter a refractory is the more insulation it will provide. But the lighter it is, the less strength and abrasion resistance it will have. In the riser, products with densities about 135 pounds per cubic foot (pcf) and higher are used. In areas of the riser with especially extreme wear, such as the wye section corners or injector nozzles, products with densities from 160 to 180 pcf with abrasion resistance of 6 cc loss down to 3 cc loss are frequently used. Other properties, such as cold crushing strength (CCS) and thermal conductivity, generally relate to abrasion resistance and density, respectively. These properties are also important, but for the sake of narrowing down the options, abrasion resistance and density are the major factors. Also important is permanent linear change (PLC, shrinkage or expansion after firing), typically measured after firing 1,500°F using ASTM C113-14.<sup>2</sup> This property should almost always be a maximum of -0.3%; the closer to 0%, the less shrinkage cracking and other issues will arise during operation. This applies to all areas of the FCCU. Most products that meet this PLC requirement also will be capable of operating in the temperature ranges found inside most FCCUs, but PLC should be double-checked when selecting refractory for any area.

The riser typically feeds directly into two sets of cyclones inside the reactor vessel. The function of the cyclones in the reactor is identical to those in the regenerator: to filter catalyst particles from the hydrocarbon products (in the reactor) or the flue gas (in the regenerator). This is done by swirling the catalyst and gases inside the cyclone at high speeds and using centrifugal force to swirl catalyst particles downward, while the gases exit through the top and into the next set of cyclones, or on to the next processing vessel. The conditions created by all this centrifugal force and particulate creates an extremely abrasive environment at temperatures in the 1,000-1,200 °F range. For this reason, the cyclones have an internal layer of abrasionresistant refractory that is usually only one inch thick. The density of the product installed inside the cyclones is irrelevant because they are contained inside the reactor or regenerator and do not require any heat insulation.

#### Refractory selection for changing conditions

Refractory selection in cyclones is based primarily on choosing the best abrasion resistance possible, but other concerns like ease of installation are also a factor. The type of refractory used here is nearly always a phosphate-bonded ramming type product. These are often referred to as plastic refractory products and are installed using a mallet or pneumatic ramming tool into hex-mesh, s-bar, or k-bar anchors. Typical plastics come premixed in slabs that can be rammed into place right out of the box with plenty of working time before they set. The downside is that they are usually heat-setting and may require some sacrificial support that will burn out during the initial firing, especially when installed overhead. Another concern with this type of phosphate-bonded plastic is that typical formulations are water soluble until fired above 650°F. So FCCUs that are started-up with steam can cause damage to

### Delicate balance in a tough environment: Refractory selection for fluid catalytic cracking units



Figure 2. Before (left) and after (right) refractory abrasion testing in accordance with ASTM C704 protocol. The example shows 11.5 cc loss on a Clipper DP refractory brick used for test demonstration purposes. Different refractories are used in abrasive situations such as the riser and should be rated at 10 cc loss or less.

this type of refractory unless treated to 650°F first.

Other types of phosphate-bonded products are designed to set exothermically at ambient conditions. These are shipped dry in a bag and mixed onsite with a special acidic solution or water to the desired consistency. The advantage of these types of materials is that they form water-insoluble linings that are resistant to the steam that might be used during startup. The disadvantage is that these materials can be very difficult to install because the set time is usually less than 15 minutes. This can lead to wasted time and material.

Regardless of which type of phosphate-bonded refractory is selected, the critical property to meet is abrasion resistance. This should be maximized as much as possible, so a maximum of 4 cc loss is often the acceptable

threshold. Areas with the worst abrasion resistance, particularly the areas immediately around the cyclone inlet, should be even less with a maximum of 2 or 3 cc loss. Materials with this level of abrasion loss typically have densities of about 170 to 180 pcf, but the density is irrelevant if the proper abrasion resistance is achieved. Phosphate-bonded products are frequently used in cyclones because these products achieve excellent strengths at the temperatures experienced here, ~1,000°F. Most cementbonded products have weaker strength in this moderate temperature range, but greater green and high-temperature strengths, in addition to a wider variety of installation options.

As described, the cyclones are contained within the reactor and regenerator. The catalyst falls out the end of the cyclones through tubes called dip-legs into a collector at the bottom of the vessels. In the bottom of the reactor, the catalyst falls over a series of baffles to interact with steam that is injected from the bottom and rises upward. This steam strips

www.ceramics.org/brick2019

ACERS STRUCTURAL CLAY PRODUCTS DIVISION & SOUTHWEST SECTION MEETING in conjunction with the National Brick Research Center Meeting



## June 24 – 27, 2019 Indianapolis, IN USA

If you are involved in the structural clay industry and that includes manufacturing, sales and marketing, consultants, and material or equipment suppliers—then join us June 24–27, 2019, at the Omni Severin Hotel in downtown Indianapolis, Indiana. This is the third year for combined meetings with ACerS Structural Clay Products, its Southwest Section, and the National Brick Research Center. extra hydrocarbons from the catalyst before the catalyst enters a transfer line to the regenerator. In the regenerator, the carbon on the catalyst burns off, which requires that the temperature in this vessel is hotter, typically around 1,500°F and up to 2,000°F. The catalyst is fluidized with an air grid on the bottom of the regenerator, and the cyclones separate flue gases from the catalyst. The catalyst collects at the base of the vessel, below the air grid. The conditions in both these vessels are less severe with respect to abrasion, particularly in the walls. This means that more insulating refractory products can be used over stronger, denser options. There are still areas with some abrasion issues, particularly in the bottom of each vessel where the catalyst collects and rubs the refractory.

In the walls of the regenerator and reactor where abrasion is lightest, a lighter weight product should be used, but some strength is still needed for long-term reliability. The density of refractory in these areas should be 70 to 90 pcf with a CCS greater than 1100 psi (after firing to 1,500°F). The refractory does not necessarily have to be abrasion resistant, so the CCS property is used to determine the strength. Using insulating refractory in the walls helps keep the heat inside the system. Too much heat loss can create problems, though some designs of FCCUs incorporate special parts off the regenerator designed to cool the catalyst to

a specified temperature. As for the bottoms of these vessels where the catalyst collects, refractory selection must find a balance between density and abrasion. Middle-weight products have been designed to work very well in these areas. They provide both low thermal conductivity and abrasion resistance but do not necessarily excel at either. These products should have a density of 100 to 130 pcf with an abrasion resistance rated to less than 12 cc loss.

Connecting all these vessels together are transfer lines. These lines contain and control the flow of catalyst between each part of the process. Slide gates in the transfer lines control the flow. Transfer lines also have some tricky thermal expansion to address between the different vessels created, so complex expansion sections are used to account for it. All the refractory on the transfer line walls should be both insulating and abrasion resistant, same as the bottom sections of the reactor and regenerator. The slide gates often experience more wear from abrasion, but also do not require as much insulation, so higher density products can be used for them.

The refractory properties required in transfer line walls are very similar to those in the reactor and regenerator. A middle-weight product with a density of 100 to 130 pcf with an abrasion loss of less than 12 cc is ideal. For the slide gates, similar products as those used in the cyclones can be rammed into hexmesh anchoring. Products with 5 cc abrasion loss or less will work well.

Proper refractory selection in the FCCU is critical to the operational requirements and overall reliability of the unit. Understanding the conditions present inside each area is just as important as understanding the properties of refractories and how they work under those conditions. Every FCCU operates differently, and conditions in one unit may be more or less severe than the next. Refractory selections should be tailored to combat special situations in each piece of the process to provide great insulating value in addition to excellent abrasion resistance and achieve the optimal balance of properties.

#### About the author

Stephen Karns is the application leader for oil refineries and petrochemical markets at HarbisonWalker International. Contact Karns at SKarns@thinkHWI.com.

#### References

<sup>1</sup>ASTM C704 / C704M-15, Standard test method for abrasion resistance of refractory materials at room temperature, ASTM International, West Conshohocken, Pa., 2015, www.astm.org, DOI: 10.1520/C0704\_ C0704M-152.

<sup>2</sup>ASTM C113-14, Standard test method for reheat change of refractory brick, ASTM International, West Conshohocken, Pa., 2014, www.astm.org, DOI: 10.1520/C0113-14

#### (continued from page 7)

A "temporary truce" to deescalate trade tensions was agreed on at the G20 Summit in Buenos Aires on Dec. 1, 2018, which resulted in the US refraining from increasing the tariffs that were slated to increase from 10 percent to 25 percent on Jan. 1, 2019.

#### Outlook for Year of the Pig

The outlook is one of expected continued tight supply of refractory raw materials from China, remaining at relatively high price levels, although unlikely to rise much higher, for the foreseeable future.

Certainly, some of the larger western refractory producers will seek to do what they can to secure and "stabilise" as much as possible mineral supply from their favoured sources in China and Refratechnik is demonstrating one way of achieving this.

But will that be enough? And what kind of guarantee of uninterrupted availability and prices can be given under these conditions? So, at the same time there will be urgent evaluation by the refractory sector for securing raw material supply outside China combined with the increasing likelihood of a stepchange in refractory formulations.

The latter will prompt use of alternative materials and more recycled materials to be assessed with more zeal, and with special regard to increasing the "recyclability" of refractories for the future.

#### About the author

Mike O'Driscoll is director of IMFORMED and has over 30 years of experience in the industrial minerals business. IMFORMED has conferences this year covering industrial minerals outlook, magnesia, oilfield, fluorspar, and India's industrial minerals—see www.imformed.com for more information. Contact O'Driscoll at mike@imformed.com.